



- 1 - CIPP Line 36" Existing under I-275 NB
- 2 - Replace CB4 in median
- 3 - Locate upstream end of existing 36" CMP that was abandoned. Leave the material in place, but Plug and Fill remaining voids under I-275 SB
- 4 - Properly Plug and Fill Manhole
- 5 - Properly Plug and Fill 36" abandoned conduit

RIM COMPLETION DATE. SEE NOTE ON SHEET 2.

CALCULATED	JEF
CHECKED	DAG

HAM-275-0528