



**Legend:**

**Gas Valve**

- ⊗ <all other values>
- ⊗ Non-Critical Valve
- Critical Valve

**Gas Mains: Distribution & Foreign**

- Distribution
- Foreign

**Gas Mains: DOT Transmission & Other**

- Transmission
- DOT Transmission
- DOT Gathering
- Pseudo-Transmission

**Gas Service**

- <all other values>
- - - Steel
- · · Cast Iron
- - - Wrought Iron
- - - Plastic
- - - Other
- - - Fittings
- Historic Map

**NOTICE**

This map reflects only the approximate location of active mains and must not be used to commit Columbia Gas of Ohio, Inc. until locations are verified and field checked by the company. BEFORE YOU DIG CALL THE OHIO UTILITIES PROTECTION SERVICE AT 1-800-362-2764 (TOLL FREE) or dial the national "Call before you dig" number, 811.

Prepared by:	
Date:	
Coordinates:	GCS (Lat/Long) in DMS. Datum: WGS84