



Legend:

Gas Valve

- ⊗ <all other values>
- ⊗ Non-Critical Valve
- Critical Valve

Gas Mains: Distribution & Foreign

- Distribution
- Foreign

Gas Mains: DOT Transmission & Other

- Transmission
- DOT Transmission
- DOT Gathering
- Pseudo-Transmission

Gas Service

- <all other values>
- Steel
- Cast Iron
- Wrought Iron
- Plastic
- Other
- Fittings
- Historic Map

NOTICE
This map reflects only the approximate location of active mains and valves. It must not be used to commit Columbia Gas of Ohio, Inc. until locations are verified and field checked by the company. BEFORE YOU DIG CALL THE OHIO UTILITIES PROTECTION SERVICE AT 1-800-362-2764 (TOLL FREE) or dial the national "Call before you dig" number, 811.

Prepared by:	
Date:	
Coordinates: GCS (Lat/Long) in DMS. Datum: WGS84	