



Ohio Department of Transportation

# CADD Engineering Standards Manual (OHDOT)

1/24/2020



This Page Intentionally Left Blank



# Table of Contents

---

|   |           |
|---|-----------|
| <b>Table of Contents</b> .....                  | <b>i</b>  |
| <b>100 GENERAL</b> .....                        | <b>4</b>  |
| <b>101 Introduction</b> .....                   | <b>4</b>  |
| 101.1 Software.....                             | 4         |
| <b>102 Distribution</b> .....                   | <b>5</b>  |
| <b>103 Revisions and Updates</b> .....          | <b>5</b>  |
| <b>104 Trademarks</b> .....                     | <b>6</b>  |
| <b>200 CADD STANDARDS</b> .....                 | <b>7</b>  |
| <b>201 Installation and Configuration</b> ..... | <b>7</b>  |
| 201.1 General.....                              | 7         |
| 201.2 Installation.....                         | 7         |
| 201.3 CADD Standards Directory.....             | 7         |
| 201.4 Configuration Variables and Files.....    | 7         |
| <b>202 Level Assignments</b> .....              | <b>7</b>  |
| 202.1 General.....                              | 7         |
| 202.2 Level Naming Convention.....              | 8         |
| 202.3 ByLevel Considerations.....               | 8         |
| 202.4 Filters.....                              | 9         |
| 202.5 Priority and Transparency.....            | 9         |
| <b>203 Colors</b> .....                         | <b>9</b>  |
| 203.1 General.....                              | 9         |
| <b>204 Line Styles</b> .....                    | <b>9</b>  |
| 204.1 General.....                              | 9         |
| 204.2 Line Style Scales.....                    | 10        |
| 204.2.1 Survey Processing using OpenRoads.....  | 10        |
| 204.2.2 Sheet Files.....                        | 10        |
| 204.2.3 Bridge Levels.....                      | 10        |
| 204.3 Plotting.....                             | 10        |
| <b>205 Line Weights</b> .....                   | <b>11</b> |
| 205.1 General.....                              | 11        |
| 205.2 Plotting.....                             | 11        |
| <b>206 Cell Libraries</b> .....                 | <b>11</b> |
| 206.1 General.....                              | 11        |
| 206.2 Cell Libraries.....                       | 11        |
| <b>207 Fonts</b> .....                          | <b>11</b> |
| 207.1 General.....                              | 11        |
| 207.2 Text Size.....                            | 12        |

|  |           |
|--|-----------|
| 207.3 Text Line Spacing .....                  | 12        |
| 207.4 Text Styles .....                        | 12        |
| 207.5 Dimension Styles .....                   | 13        |
| <b>208 Seed Files .....</b>                    | <b>14</b> |
| 208.1 General.....                             | 14        |
| 208.2 Models.....                              | 14        |
| <b>209 Working Units.....</b>                  | <b>14</b> |
| 209.1 General.....                             | 14        |
| <b>210 Global Origin .....</b>                 | <b>15</b> |
| 210.1 General.....                             | 15        |
| <b>211 Custom Applications.....</b>            | <b>15</b> |
| 211.1 General.....                             | 15        |
| <b>212 OpenRoads Standards .....</b>           | <b>15</b> |
| 212.1 General.....                             | 15        |
| 212.2 DGN Libraries.....                       | 15        |
| 212.3 Template Libraries .....                 | 16        |
| <b>300 FILE MANAGEMENT .....</b>               | <b>17</b> |
| <b>301 General .....</b>                       | <b>17</b> |
| 301.1 General.....                             | 17        |
| <b>302 Project Directory Structure .....</b>   | <b>17</b> |
| 302.1 Standard Directory Structure .....       | 17        |
| 302.2 OHDOTCreateWorkSet.exe .....             | 17        |
| <b>303 References .....</b>                    | <b>18</b> |
| 303.1 General.....                             | 18        |
| 303.2 Models.....                              | 18        |
| 303.2.1 Model Types .....                      | 18        |
| 303.3 Basemap Design Files .....               | 18        |
| 303.4 Sheet Design Files .....                 | 19        |
| <b>304 File Naming Conventions.....</b>        | <b>20</b> |
| 304.1 General.....                             | 20        |
| 304.2 File Extensions.....                     | 20        |
| 304.3 File Name Format.....                    | 21        |
| 304.4 Supplemental Description Guidelines..... | 22        |
| Figure 304-1 File Name Type Codes.....         | 23        |
| <b>305 Geographic Coordinate Systems.....</b>  | <b>27</b> |
| 305.1 General.....                             | 27        |
| <b>306 OpenRoads Designer .....</b>            | <b>27</b> |
| 306.1 Federated Files.....                     | 27        |
| 306.1.1 Alignment Design Files .....           | 27        |
| 306.1.2 Corridor Modeling Design Files .....   | 27        |
| 306.1.3 Survey Design Files.....               | 27        |

|  |           |
|--|-----------|
| 306.1.4 OpenRoads Subsurface Utilities Files ..... | 28        |
| 306.2 Alignment Names for OpenRoads Designer ..... | 28        |
| 306.3 Survey Point Names.....                      | 30        |
| <b>400 PLOTTING.....</b>                           | <b>31</b> |
| <b>401 General .....</b>                           | <b>31</b> |
| 401.1 General.....                                 | 31        |
| 401.2 Plotting.....                                | 31        |
| 401.2.1 Line Weights .....                         | 32        |
| 401.2.2 Priority and Transparency .....            | 32        |
| 401.2.3 Shading .....                              | 33        |
| 401.2.4 Masking.....                               | 33        |
| 401.2.5 Text Substitution .....                    | 33        |
| 401.2.6 Color Plotting.....                        | 34        |

**APPENDIX - Levels** [Click Here](#)

**APPENDIX - Colors** [Click Here](#)

**APPENDIX - Line Styles** **Coming Soon**

**APPENDIX - Cells** **Coming Soon**

**APPENDIX - Project Folders** [Click Here](#)

**APPENDIX - File Naming Format** [Click Here](#)

**Guidelines for Electronic Design Deliverables** [Click Here](#)

## 100 GENERAL

---

### 101 Introduction

Computer-Aided Drafting and Design (CADD) is the preferred method of preparing plans for the Ohio Department of Transportation (ODOT). The requirements presented in this manual ensure that CADD files can be used by the entire project team (surveyors, planners, environmentalists, designers, reviewers, contractors, etc.) throughout all phases of project development.

ODOT has adopted MicroStation CONNECT Edition (CE) and OpenRoads Designer CONNECT Edition (ORD) as its standard drafting and design software packages, respectively. The standards referenced in this manual have been developed and tested using the MicroStation CE and ORD software versions listed on the [ODOT CADD Services](#) webpage.

The April 2019 update to ODOT's CADD Standards included new "OHDOT" Standards for use with MicroStation CE and ORD. The new Standards are compatible with MicroStation CE and ORD and are not backwards compatible with previous software versions. The new Standards replace the previous "ODOTcadd" standards for all projects developed using MicroStation CE and ORD.

All new projects started after April 1, 2020 using Bentley software must use MicroStation CE or ORD using the OHDOT Standards. Projects started after April 1, 2020 are not permitted to use the ODOTcadd standards. Information about ODOT's transition from MicroStation and GEOPAK SELECTseries 4 to MicroStation CE and ORD is available on the [ODOT CADD Services](#) webpage.

This manual supersedes all CADD standards previously published in the Bridge Design Manual, the Right-of-Way Manual, and the [Location and Design Manual, Volume 3](#).

This manual is not a textbook and does not exempt the professional from performing responsible engineering and/or surveying. It is intended to provide uniform procedures and standards for ODOT staff and organizations that perform CADD related services for ODOT. The professional shall have final responsibility for the accuracy of all input and output of computer-based applications.

#### **101.1 Software**

ODOT operates internally using MicroStation CONNECT Edition (CE) and OpenRoads Designer CONNECT Edition (ORD) software only.

ODOT will accept electronic deliverables generated from Autodesk tools; however, the CADD design software to be used on a project shall be mutually agreed upon by the District and consultant and shall be explicitly stated in the project's scope of services. Once the decision has been made to use either MicroStation CE, OpenRoads Designer, or Autodesk, there shall be no deviation from the agreed upon design package, and the same one shall be used until the project's completion.

This document is specific to ODOT's use of MicroStation CE and ORD. ODOT will provide no support, standards, documentation, or guidance of any kind with respect to design and delivery of projects developed using Autodesk tools. All CADD related documentation, training, supporting files, and customization provided by ODOT shall be MicroStation CE and ORD based only.



A Civil3D State Kit for use with Autodesk software is available for ODOT projects. A link to download the State Kit is provided on the [ODOT CADD Services](#) webpage.

ODOT offers no support for the Autodesk Civil3D State Kit.

The final deliverables of an Autodesk designed project in printed or electronic format shall mimic that of a project designed and delivered using MicroStation CE/ORD. The electronic deliverables for projects designed using Autodesk tools shall be delivered in the native Autodesk format, and not converted to MicroStation CE/ORD format.

## **102 Distribution**

This manual, in its entirety, may be freely copied and distributed for the purpose of providing a consistent guide to the CADD requirements of the Ohio Department of Transportation. The manual, Standard CADD files and other support files can be downloaded from the [ODOT CADD Services](#) webpage.

For ODOT CADD Users, MicroStation CE and ORD CADD Standards are located inside ProjectWise and are configured to be used inside the ProjectWise environment.

## **103 Revisions and Updates**

The **Office of CADD and Mapping Services**, CADD Section, with input from ODOT's District Offices, technical offices, and the consultant and construction community, will develop, and maintain procedures and standards for the Department's CADD related activities. CADD Manual holders are encouraged to submit comments and suggestions for improvements to the manual or ODOT's CADD Standards. Any errors found should be brought to the attention of the ODOT **Office of CADD and Mapping Services** via the following online support request:

[https://odot.formstack.com/forms/cadd\\_servicerequest](https://odot.formstack.com/forms/cadd_servicerequest)

The Ohio Department of Transportation strives to stay current with state-of-the-art trends in the market. However, impacts on project delivery schedules and the resources necessary to provide future support for new features must be considered prior to any change.

Updating this manual is intended to be a continuous process and revisions will be issued periodically per the release dates stated on the **Design Reference Resource Center (DRRC)** web page at the following address:

<http://www.dot.state.oh.us/drrc/Pages/default.aspx>

The DRRC web page also provides the option to subscribe to an email list for notification of updates to ODOT's Standard CADD Files. Once you have subscribed to the ODOT CADD Standards mailing list, it is your responsibility to notify ODOT of a change of email address by unsubscribing your old email address and re-subscribing using your new email address. See the DRRC web page for instructions on subscribing and unsubscribing.

Revisions to the manual are noted in red text.

January 24, 2020

## **104 Trademarks**

MicroStation CONNECT and OpenRoads Designer are registered trademarks of Bentley Systems, Incorporated. © 2019 Bentley Systems, Incorporated.

Autodesk is a registered trademark of Autodesk, Incorporated.

Other trade names, computer protocols, and file formats mentioned in this manual are the trademarks of their respective owners. In no event will the appearance of any graphic, description of any graphic, picture, screen display, or any other method of conveying meaning be considered to impair the rights of the respective owners.

## **200 CADD STANDARDS**

---

### **201 Installation and Configuration**

#### **201.1 General**

This section outlines the setup for a typical installation of MicroStation CE and ORD at ODOT. The configuration files discussed in this section are available from the ODOT CADD Standards website.

The OHDOT Standards can be downloaded from the [ODOT CADD Services](#) webpage.

#### **201.2 Installation**

For a typical ODOT installation, MicroStation CE and ORD software is installed in the default location.

#### **201.3 CADD Standards Directory**

The configuration and associated files for MicroStation Connect and OpenRoads Designer that are used for plan development at ODOT are located within ProjectWise at the following location:

Ohio DOT Projects\Documents\03 Standards\CADD Standards\CONNECT\_Config\Workspaces\OHDOTCEv01\

Configuration information for users external to ODOT can be found on the [ODOT CADD Services](#) webpage.

#### **201.4 Configuration Variables and Files**

Configuration variables are defined in two locations within the OHDOT CADD Standards environment:

- OHDOT\_WorkSpace.cfg defines configuration variables and standards that apply to all projects developed using the OHDOT Workspace.
- Project specific variables are defined in a WorkSet Configuration file.

The OHDOT Workspace does not define a custom location for user configuration files. User configuration files are in the default directory as defined by Bentley software.

### **202 Level Assignments**

#### **202.1 General**

ODOT has developed a standard set of levels to be used with all design files submitted to or exchanged with the Department. The levels are defined in a MicroStation DGN Library, OHDOT\_Feature\_Definitions.dgnlib.

Users shall not create their own levels for use in any design files submitted or exchanged with ODOT.

See the [Appendix - Levels](#), for a complete list of the ODOT levels.

## 202.2 Level Naming Convention

ODOT level names use the following naming convention:

### Classification\_Disposition\_Logical Name

The **Classification** consists of two (2) uppercase characters used to group the levels into categories. The Classification names are listed in the table below:

| Classification | Description            | Classification | Description         |
|----------------|------------------------|----------------|---------------------|
| AP             | Airports               | PF             | Profiles            |
| BD             | Buildings              | PM             | Pavement Markings   |
| BR             | Bridge                 | PV             | Pavement            |
| CL             | Centerline             | RC             | Recreational        |
| CM             | Corridor Modeling      | RD             | Roadway             |
| DR             | Drainage               | RS             | Raster Files        |
| DT             | Digital Terrain Models | RW             | Right-of-Way        |
| DV             | Divisions              | SC             | Scratch             |
| EV             | Environmental          | SG             | Signals             |
| FL             | Flight Mapping         | SH             | Sheets              |
| GE             | Geometry               | SN             | Signing             |
| GK             | GEOPAK                 | SV             | Survey              |
| GT             | Geotechnical           | TR             | Truck Turning Paths |
| HY             | Hydraulics             | TX             | Text                |
| LT             | Lighting               | UT             | Utilities           |
| MD             | Modeling               | VG             | Vegetation          |
| MT             | Maintenance of Traffic | VL             | Volume              |
| PC             | Point Clouds           | XS             | Cross Section       |

The **Disposition** is used to identify the level for placement of either **X** (existing) or **P** (proposed) information.

The **Logical Name** is used as a description of the element contents. Where appropriate, common industry abbreviations are used.

All ODOT levels names use alphanumeric characters only. No spaces or special characters are used other than the underscore “\_” character.

## 202.3 ByLevel Considerations

In general, to facilitate use of MicroStation’s ByLevel attributes, the ODOT levels have been established such that each curvilinear feature will have its own level. In order to keep the overall number of levels manageable, there are cases where similar features will be placed on the same

level making it impossible to use ByLevel attributes for those features. Some exceptions are noted below:

- Standard ODOT cells are placed on the level in which they were created. Each cell is not placed on its own level, rather, like cells are grouped on one level. For example, existing electric utility cells are all placed on the level UT\_X\_Electric\_Cells.
- Storm Sewer Lines – Each proposed storm sewer line 12” and above will be placed using the custom line style “stormline”, which shall be scaled, based on the pipe size. All proposed storm sewer lines will be placed on the level DR\_P\_Storm\_Sewer.
- Culvert Lines – Each proposed culvert line will be placed using a custom line style based on the culvert size. All proposed culvert lines will be placed on the level DR\_P\_Culvert.
- Maintenance of Traffic Drums – Multiple line styles have been created to represent various typical drum spacing’s. These lines are placed on level MT\_P\_Drums.

## 202.4 Filters

ODOT’s level library, found in **OHDOT\_Feature\_Definitions.dgnlib**, has been configured with a set of default level filters that can be used to control the display of levels based on their attributes. Users shall not edit or delete the default filters.

## 202.5 Priority and Transparency

The levels defined in **OHDOT\_Feature\_Definitions.dgnlib** utilize MicroStation’s Element Priority and Transparency functions. The priorities and transparencies are preset and based on what level is being used and should not be changed. See the [Appendix – Levels](#), for a complete list of Priority and Transparency values.

## 203 Colors

### 203.1 General

Standard colors are specified to ensure consistency and to enable users to easily identify plan elements in shared files. For uniformity, the ODOT color table must be used and shall not be altered. See the [Appendix – Colors](#), for a complete list of ODOT’s color table values.

Note: The color values may vary or appear different on screen due to the difference in graphics cards, monitors display capability, etc.

## 204 Line Styles

### 204.1 General

Line styles are used to differentiate curvilinear elements in the design file and on the plotted sheet. ODOT uses Bentley’s default line styles, zero (0) through seven (7), along with ODOT’s developed set of Custom Line Styles. The line styles must be used to provide consistency and uniformity across plans.

The custom line style definitions are stored in a MicroStation DGN Library, OHDOT\_Feature\_Definitions.dgnlib.

Users shall not create their own custom line styles for use on ODOT plan sheets.

Standard line codes and custom line styles for plan graphics are specified in the [Appendix – Levels](#) and displayed in **Appendix – Line Styles**.

## 204.2 Line Style Scales

The location and dimensions of all plan view basemap design file information shall be drawn in the Design model using real world dimensions at a 1:1 scale. Custom Line Styles are to be placed in the basemap at a scale of one (1) so the Drawing Scale feature can be used.

Referenced basemap design files when referenced into another file should have the line style scale set to Annotation Scale for proper scaling inside the new file.

### 204.2.1 Survey Processing using OpenRoads

Survey data processed using OpenRoads Survey is drawn at real world dimensions. Line Styles are according to the current MicroStation Drawing Scale setting and will respond to changes in the Drawing Scale value.

For more detailed information processing survey data using OpenRoads Designer, see the **ODOT OpenRoads Survey training guide**.

### 204.2.2 Sheet Files

For basemap design files referenced into sheet files, the global line style scale must be set to Master for proper scaling to match the sheet file.

### 204.2.3 Bridge Levels

Several line styles have been developed specifically for use on Bridge plans that are not always placed at a specific scale relative to the plotting scale. The line styles listed in the table below shall be scaled as necessary to produce a legible detail. These line styles are assigned to the appropriate level by use of ByLevel attributes.

| Line Style Name | Description  |
|-----------------|--|
| bcenterline     | Centerline   |
| bconstruction   | Construction Joint / Phase Construction Line                             |
| bexisting       | Existing Objects (all existing lines except existing reinforcement bars) |
| bhiddenpr       | Hidden Line Proposed   |
| brebarpr        | Proposed Reinforcement Bars  |
| brebarex        | Existing Reinforcement Bars  |

## 204.3 Plotting

The dash and gap lengths of the MicroStation default line codes 0-7 are defined by the plotting software. See **Section 400 - Plotting** for the ODOT plotting values for line codes 0-7.

## 205 Line Weights

### 205.1 General

Line weights are used to differentiate graphical elements in the design file and on the plotted sheet. Line Weight width ranges from weight zero (narrowest) to weight 31 (widest) and designate the thickness of the line used to draw or plot a graphic element.

Default line weights per level are specified in the [Appendix - Levels](#).

### 205.2 Plotting

See **Section 400 - Plotting** for information on line weight plotting thickness values.

## 206 Cell Libraries

### 206.1 General

For plan consistency, ODOT provides standard cell libraries containing cells representing items that will be repeatedly placed in a design file. Several ODOT standard cell libraries are available as detailed in **Section 206.2 - Cell Libraries**.

### 206.2 Cell Libraries

The following cell libraries are available to facilitate the drawing of commonly used symbols and sheet borders as described below:

| Cell Library                   | Description  |
|--------------------------------|--|
| OHDOT_Bridge.cel               | Cells used for bridge plans                          |
| OHDOT_Drainage.cel             | Cells used for 2D standard drainage structures       |
| OHDOT_DrainageAndUtilities.cel | Cells used for standard drainage structures for SUDA |
| OHDOT_Geotech.cel              | Cells used for geotechnical information              |
| OHDOT_Labels.cel               | Cells used for ORD plan labels                       |
| OHDOT_RW.cel                   | Cells used for right-of-way plans                    |
| OHDOT_Sheets.cel               | Cells used for standard plan sheet borders           |
| OHDOT_Symbols.cel              | Cells representing standard plan symbols             |

Additionally, a set of cell libraries including standard signs from the **Office of Roadway Engineering**, Sign Designs and Markings Manual is included in the OHDOT CADD Standards. These sign cells are easily placed using a custom application, also provided in the OHDOT CADD Standards.

## 207 Fonts

### 207.1 General

The TrueType font Arial will be used for all plans developed using the OHDOT CADD Standards.

To supplement the use of font Arial, the OHDOT Workspace includes a custom symbol font, **OHDOTSymbols.ttf**, containing commonly used engineering symbols.

## 207.2 Text Size

Standard text sizes have been defined to ensure uniform legibility of all plan sheets. Standard text size refers to the size of the text on a full sized (22"x34") sheet, not the text size in the design file.

| Text Type  | Plotted Text Size |
|------------|-------------------|
| Normal     | 0.14"             |
| Subtitle   | 0.17"             |
| Title      | 0.20"             |
| Main Title | 0.25"             |

Text sizes smaller than the Normal text size are not acceptable.

For all ODOT plans, the preferred method to set the text size is by use of the Model Annotation Scale parameter. See **Section 207.4 - Text Styles** for more information.

## 207.3 Text Line Spacing

In general, Text Line Spacing should be one-half (0.50") the text height. The spacing between lines on summary, sub-summary, general note sheets and charts is generally equal to the minimum text size. If needed, it is permissible to use Text Line Spacing equal to the minimum text size.

## 207.4 Text Styles

ODOT's standard text styles are defined in a MicroStation DGN Library, **ODOT\_Styles\_TextDim.dgnlib**.

The following Text Styles have been configured for use on ODOT plans:

| Text Style                       | Text Size* | Spacing* | Font  |
|----------------------------------|------------|----------|-------|
| Slanted - Normal Fixed Spacing   | 0.14       | 1.00     | Arial |
| Slanted - Normal LS=0.50         | 0.14       | 0.50     | Arial |
| Slanted - Normal LS=0.50 Masked  | 0.14       | 0.50     | Arial |
| Slanted - Normal LS=0.75         | 0.14       | 0.75     | Arial |
| Slanted - Normal LS=1.00         | 0.14       | 1.00     | Arial |
| Slanted - Sub Title              | 0.17       | 0.50     | Arial |
| Slanted - Title                  | 0.20       | 1.00     | Arial |
| Straight - Normal Fixed Spacing  | 0.14       | 1.00     | Arial |
| Straight - Normal LS=0.50        | 0.14       | 0.50     | Arial |
| Straight - Normal LS=0.50 Masked | 0.14       | 0.50     | Arial |
| Straight - Normal LS=0.75        | 0.14       | 0.75     | Arial |
| Straight - Normal LS=1.00        | 0.14       | 1.00     | Arial |
| Straight - Sub Title             | 0.17       | 1.00     | Arial |
| Straight - Title                 | 0.20       | 1.00     | Arial |



|              |      |      |             |
|--------------|------|------|-------------|
| Title        | 0.20 | 0.50 | Arial Black |
| Title – Main | 0.25 | 0.50 | Arial Black |
| Title - Sub  | 0.17 | 0.50 | Arial Black |

\*Text size and Line Spacing units are Master Units.

**Note:** There are additional text styles included in the OHDOT CADD Standards. These text styles, which are not listed above, are configured for specific ORD labeling tasks and are not normally selected by the user for general plan preparation annotation purposes.

All text placed on Bridge sheets, excluding text contained in standard border cells, shall use the “**Slanted**” text styles.

See the [Location and Design Manual, Volume 3](#), the [Bridge Design Manual](#), and the [Specifications for Geotechnical Explorations \(SGE\)](#) for recommended sheet scales.

## 207.5 Dimension Styles

ODOT has configured a set of dimension styles to be used on ODOT plans. These styles are defined in the ODOT Standard DGN Library, **OHDOT\_Text\_Dimension\_Styles.dgnlib**, which can be obtained from the [ODOT CADD Standards](#) website.

The following dimension styles have been defined in **OHDOT\_Text\_Dimension\_Styles.dgnlib**:

| Dimension Style                  | Font  | Text Size* | Description                     |
|----------------------------------|-------|------------|---------------------------------|
| Dec-0, Masked, Slanted           | Arial | 0.14       | Decimal Feet, No decimal places |
| Dec-0, Masked, Straight          | Arial | 0.14       | Decimal Feet, No decimal places |
| Dec-1, Masked, Slanted           | Arial | 0.14       | Decimal Feet, 1 decimal places  |
| Dec-1, Masked, Straight          | Arial | 0.14       | Decimal Feet, 1 decimal places  |
| Dec-2, Masked, Slanted           | Arial | 0.14       | Decimal Feet, 2 decimal places  |
| Dec-2, Masked, Straight          | Arial | 0.14       | Decimal Feet, 2 decimal places  |
| Dec-Multiline, Masked, Slanted   | Arial | 0.14       | Decimal Feet, 0.01 accuracy     |
| Dec-Multiline, Masked, Straight  | Arial | 0.14       | Decimal Feet, 0.01 accuracy     |
| Fract, Masked, Slanted           | Arial | 0.14       | Fractions, 1/16” accuracy       |
| Fract, Slanted                   | Arial | 0.14       | Fractions, 1/16” accuracy       |
| Fract-Multiline, Masked, Slanted | Arial | 0.14       | Fractions, 1/16” accuracy       |

\*Text size units are Master Units.

**Note:** There are additional dimension styles included in the OHDOT CADD Standards. These dimension styles, which are not listed above, are configured for specific ORD labeling tasks and are not normally selected by the user for general plan preparation annotation purposes.

Line Terminators shall be a filled arrow created with a width to height ratio of 2.5:1. The terminator width shall equal the text height.

Leader Lines may be broken when crossing dimension lines. In order to keep broken lines to a minimum, it is recommended that the user relocate the dimension callout or reposition the dimension. Leader lines and terminators shall be a weight of zero (0) and shall be placed on the same level as required for text notes and callouts.

Like Text Styles, the text size for Dimension Styles is set by use of the Model Annotation Scale parameter.

Bridge plans shall use the “**Fract, Slanted**”, “**Fract-Multiline, Slanted**” or “**Masked Fract, Slanted**”, “**Masked Fract-Multiline, Slanted**” dimension styles. All Bridge dimensions shall be placed associated.

Dimensions shall not have their status dropped.

## **208 Seed Files**

### **208.1 General**

MicroStation uses a “seed file” to create all design files. A seed file is a template in which standard parameters are set. Seed files do not typically contain elements, but like other design files they do contain settings like working units and view configurations. Using a standard, customized seed file helps maintain uniformity and keeps the user from having to adjust design file settings each time a file is created.

The following seed files are included with the OHDOT CADD Standards download. The Geographic Coordinate System (GCS) for each seed file is defined as shown in the table below:

| <b>Dimension</b> | <b>Seed File Name</b>         | <b>Geographic Coordinate System</b> |
|------------------|-------------------------------|-------------------------------------|
| 2D               | OHDOT_Seed2d.dgn              | None                                |
| 2D               | OHDOT_Seed2d_OH83-2011-NF.dgn | OH83-2011-NF                        |
| 2D               | OHDOT_Seed2d_OH83-2011-SF.dgn | OH83-2011-SF                        |
| 2D               | OHDOT_Seed2d_OH83-NF.dgn      | OH83-NF                             |
| 2D               | OHDOT_Seed2d_OH83-SF.dgn      | OH83-SF                             |
| 3D               | OHDOT_Seed3d.dgn              | None                                |
| 3D               | OHDOT_Seed3d_OH83-2011-NF.dgn | OH83-2011-NF                        |
| 3D               | OHDOT_Seed3d_OH83-2011-SF.dgn | OH83-2011-SF                        |
| 3D               | OHDOT_Seed3d_OH83-NF.dgn      | OH83-NF                             |
| 3D               | OHDOT_Seed3d_OH83-SF.dgn      | OH83-SF                             |
| 2D               | OHDOT_DrawingSeed2d.dgn       | None                                |
| 2D               | OHDOT_SheetSeed2d.dgn         | None                                |

### **208.2 Models**

ODOT’s seed files are defined to include only one MicroStation Model. The seed files are defined with a Design, Sheet, or Drawing model according to the intended usage file.

## **209 Working Units**

### **209.1 General**

The OHDOT CADD Standards include a standard unit definition file, **ODOT\_Units.def**, to define the U.S. Survey Foot as the standard Master Unit.

MicroStation design files used in plan preparation shall use the following standard working units as defined in the ODOT seed files and in **ODOT\_Units.def**:

| Unit Names               | Label |
|--------------------------|-------|
| Master Unit: Survey Feet | '     |
| Sub Unit: Inches         | "     |

The ODOT seed files have been defined with a standard resolution setting of 12000 per Survey Foot. This setting shall not be changed by the user.

ODOT's seed files are set up with the standard working units described above. Deviation from these working units is not permitted.

## **210 Global Origin**

### **210.1 General**

Elements in the design file are drawn by placing data points. Each data point placed in the design plane has associated X (easting), Y (northing) and Z (elevation, 3D files only) positions or coordinates. The design plane is simply a Cartesian coordinate system upon which your design model lies.

In the ODOT Seed files, the point called the Global Origin is set to the design plane's exact center and assigned the coordinates 0,0 (2D files) and 0,0,0 (3D files).

The Global Origin is defined in ODOT's Seed Files and should never be changed for ODOT projects.

## **211 Custom Applications**

### **211.1 General**

ODOT has written several programs to assist the user with specific CADD related functions. Each application can be accessed from the MicroStation CE or ORD Ribbon by selecting the OHDOT workflow.

## **212 OpenRoads Standards**

### **212.1 General**

The OHDOT Standards include several new standard files defined for use with Bentley's OpenRoads Designer.

### **212.2 DGN Libraries**

Several MicroStation DGN Libraries have been configured within the OHDOT workspace, for use with MicroStation CE and ORD, as detailed below.

January 24, 2020

**ODOT\_DesignStandards.dgnlib**

This DGN Library defines the Design Standards for Horizontal and Vertical alignments according to various standards defined in the Location and Design Manual, Volume 1 - Roadway Design.

**ODOT\_Feature\_Definitions.dgnlib**

This DGN Library defines OpenRoads features for design and survey, as well as the MicroStation levels and element templates. The DGN Library also defines the default Survey Settings for OpenRoads.

**OHDOT\_Features\_DrainageAndUtilities.dgnlib**

This DGN Library defines OpenRoads features for subsurface utility modeling, computation, and analysis.

### 212.3 Template Libraries

ODOT provides a template library, **OHDOT\_Templates.itl**, with several templates and components that can be used as a starting point to design the typical sections for the proposed roadway corridor.

## 300 FILE MANAGEMENT

---

### 301 General

#### 301.1 General

File management refers to how documents are organized and stored. Its primary purpose is to provide a safe repository for information and to minimize the possibility of that information being lost.

The folder structure details listed below are for use on ODOT projects developed with MicroStation CE or ORD. All plans using either program must follow the folder structure established by ODOT.

### 302 Project Directory Structure

#### 302.1 Standard Directory Structure

A standard project directory shall be used to house all project related data for the various workflows involved in the project development process throughout the lifecycle of the project.

Alphanumeric characters, a dash "-", an underscore "\_", or a period "." are the only characters permitted in folder names. No other special characters, or spaces, are permitted in any folder name.

Internally, ODOT projects developed using MicroStation CE or ORD will be stored in ProjectWise. Projects are stored in the following dataset within the ProjectWise environment:

Ohio DOT Projects\01 Active Projects\District ##\County\PID Number\

A template folder structure is used for all projects, starting from the PID number. This template folder structure is used for all projects, both internal and external to ODOT. See [Appendix - Project Folders](#) for the documented template folder structure.

A template folder structure is provided in the OHDOT CADD Standards in the following location:

..\OHDOT\Standards\WorkSetTemplates\000000\_OHDOT\_Template

In MicroStation CE and ORD the project folder structure is also referred to as a "WorkSet".

#### 302.2 OHDOTCreateWorkSet.exe

The OHDOT WorkSet Creation Tool is a standalone resizable C# Windows Presentation Form application that is fully integrated with ProjectWise.

This application is used to assist in creating new project "Worksets" and can be launched from within the standards:

..\OHDOT\Standards\Applications\OHDOTCreateWorkSet.exe

It can also be launched from the MicroStation CE or ORD ribbon within the OHDOT Workflow > Apps tab.

For more information on using the OHDOT Workset Creation Tool please refer to our tutorial videos.

[https://communities.bentley.com/communities/user\\_communities/ohio\\_dot\\_consultants/w/ohio\\_dot---wikis/46259/create-workset](https://communities.bentley.com/communities/user_communities/ohio_dot_consultants/w/ohio_dot---wikis/46259/create-workset)

## **303 References**

### **303.1 General**

References are used to display the contents of one design file in another design file to facilitate the design process (i.e. display the existing survey data in the proposed right-of-way basemap).

### **303.2 Models**

#### **303.2.1 Model Types**

MicroStation CE and ORD provide three types of models, intended for different uses. ODOT uses these model types for the following purposes:

- **Design** models are used for creating design geometry that can be either 2D or 3D. All basemap information shall be drawn in a design model.
- **Drawing** models are used in the ORD sheet clipping process to reference the design model which in turn references various basemap design files. The drawing model is also used to place the annotations that will be displayed on the sheets. A drawing model is always a 2D model.
- **Sheet** models are used to assemble the plan sheets that are used for plotting a set of plans that can be either 2D or 3D. Sheet border cells are placed in the Sheet model.

### **303.3 Basemap Design Files**

Basemap design files are used to draw existing and proposed plan view information for the entire length of the project for both Roadway and Bridge projects.

Plan view information is separated into multiple discipline-specific basemap design files as listed below:

| <b>Allowable Plan View Basemap Files</b> |                        |
|--|------------------------|
| Aerial Mapping                           | Lighting               |
| Bridge                                   | Maintenance of Traffic |
| Drainage                                 | Proposed Roadway       |
| Environmental                            | Right-of-Way           |
| Existing Ground Survey                   | Signals                |
| Geometry                                 | Traffic Control        |
| Geotechnical                             | Utilities              |

|             |       |
|-------------|-------|
| Landscaping | Walls |
|-------------|-------|

All basemap information shall be drawn in the **Design** model.

The location and dimensions of all plan view basemap design file information shall be drawn using real world dimensions at a 1:1 scale. If a bridge basemap is used, a separate basemap design file is required for each bridge on the project.

A separate cross section basemap should be used for each alignment in the project. Cross sections should always be plotted in their own design file and never combined with any other basemap.

All basemap design files shall be stored in the appropriate discipline specific basemaps sub-directory and shall not be copied into another sub-directory for editing or referencing.

### 303.4 Sheet Design Files

Sheet design files are used to assemble the plan sheets that are used for plotting a set of plans.

Sheet design files can be generated using OpenRoads tools or generated manually using MicroStation reference tools.

When sheets are generated using the OpenRoads tools, the Drawing model is used to place all annotation for the sheet. The Sheet model contains the sheet border information and references the related drawing model(s).

When sheets are generated manually, the sheet design files are assembled by referencing Design models from the various basemap design files to the sheet model of the sheet file. Sheet border cells and annotation are typically placed in the sheet model.

For Bridge sheets, a single design file may include both existing and proposed plan view information.

Final plan sheets shall be in the Sheet Model. No items other than what is shown on the final plotted sheet can be shown in the Sheet Model. Any detail shown in the final plotted sheet shall be represented at a 1:1 scale in either the Design model, Drawing model, or Sheet model of the corresponding file.

Each plan sheet shall be contained within the Sheet Model. Only one plan sheet per model is permissible for all file types, including cross sections. Users may elect to create multiple sheet models in a sheet design file. Only sheets of a like type are permitted in a multi-model sheet design file. For example, it is not permissible to create a design file containing the title sheet in one model and the schematic plan in a second model.

When sheet design files are submitted to the Department, no other graphics are permitted in the Sheet model other than the graphics representing the final plotted sheet. All extra graphics used to generate the sheet, or old versions of the sheet, should be deleted or moved to a design model. No extra reference attachments that are not a part of the final sheet are permitted to be attached to the sheet model.

To ensure that reference file attachments are maintained when moving project files from the original project directory to another location, references shall be attached using relative paths. The user shall not use MicroStation option to “Save Full Path” for reference attachments.

All completed sheet design files submitted to or exchanged with ODOT shall use references where applicable. It is not recommended that users copy referenced graphics into the sheet files for the completed sheet design files submitted to ODOT.

## **304 File Naming Conventions**

### **304.1 General**

The efficient sharing and transfer of information from consultants/contractors to ODOT and vice versa relies on the use of a systematic file naming convention. This section outlines a consistent, comprehensive file naming convention for graphic and associated files used in the CADD environment, which shall be used for all projects.

With such large quantities of data being created, it is essential that operators create their new files with names that signify the content of each. Therefore, each sheet of the plan shall be contained in its own separate design file.

Standard naming conventions shall be used for all design files. Document all file names, both standard and project specific, in the Project Index file (For information on the **Project Index File**, see **ODOT’s Guidelines for Electronic Deliverables**). In the event a particular file type for the project is not addressed by this manual, use the file naming convention as a template for selecting an appropriate name or contact the **Office of CADD and Mapping Services’ CADD Services** section for assistance.

In order to avoid conflicting attachments of reference files, there shall be no duplicate file names within the project directory structure or copies of the same file within the project directory. It is not permissible to copy the same basemap design files into multiple discipline specific sub-directories.

### **304.2 File Extensions**

Standard file name extensions for information submitted to, or exchanged with, ODOT shall be as follows:

| <b>File Type</b>             | <b>Extension</b> |
|------------------------------|------------------|
| Bentley Design File          | .dgn             |
| Bentley Cell Libraries       | .cel             |
| Portable Document Format     | .pdf             |
| Microsoft Word Documents     | .doc or .docx    |
| Microsoft Excel Spreadsheets | .xls or .xlsx    |
| XML Files                    | .xml             |

For file types not listed above, the default file extension defined by the software shall be used.



### 304.3 File Name Format

ODOT has defined the following naming convention to be used on all design files submitted to or exchanged with the Department.

Files shall be named as follows:

#### Design File Naming Format

nnnnnn\_aa###.dgn

- nnnnnn = Five (5) or Six (6) digit PID Number
- aa = Two (2) letter code identifying the plan sheet type  
(see **Figure 304-1 - File Name Type Codes**)
- ### = Three (3) digit number identifying the number of drawings of the same type. The three-digit number is required even if there is only one drawing of a type in the plan set.

Examples:

123456\_BE001.dgn

123456\_GP005.dgn

Bridge, culvert and wall design files have unique file naming requirements, as detailed below:

#### Bridge Design File Naming Format

nnnnnn\_SFNyyyyyyy\_aa###.dgn

- nnnnnn = Five (5) or Six (6) digit PID Number
- yyyyyyy = Seven (7) digit SFN number of the structure
- aa = Two (2) character bridge plan sheet type  
(see **Figure 304-1 - File Name Type Codes**)
- ### = Three (3) digit number identifying the number of drawings of the same type. The three-digit number is required even if there is only one drawing of a particular type in the plan set.

Examples:

123456\_SFN1234567\_SD002.dgn

#### Culvert Design File Naming Format

nnnnnn\_CFNyyyyyyy\_aa###.dgn

- nnnnnn = Five (5) or Six (6) digit PID Number
- yyyyyyy = Seven (7) digit CFN number of the culvert
- aa = Two (2) character drainage plan sheet type  
(see **Figure 304-1 - File Name Type Codes**)
- ### = Three (3) digit number identifying the number of drawings of the same type. The three-digit number is required even if there is only one drawing of a particular type in the plan set.

Examples:

123456\_CFN1234567\_DC006.dgn

|                                       |
|---------------------------------------|
| <b>Wall Design File Naming Format</b> |
|---------------------------------------|

nnnnnn\_WALLyyy\_aa###.dgn

- nnnnnn = Five (5) or Six (6) digit PID Number
- yyy = Three (3) digit wall number (three digits required and maximum).
- aa = Two (2) digit wall plan sheet type  
(see **Figure 304-1 - File Name Type Codes**)
- ### = Three (3) digit number identifying the number of drawings of the same type. The three-digit number is required even if there is only one drawing of a particular type in the plan set.

Examples:

123456\_WALL001\_WP005.dgn  
123456\_WALL002\_WS001.dgn

### 304.4 Supplemental Description Guidelines

ODOT allows users to provide supplemental description information by use of MicroStation’s File Properties. The intent of the supplemental description is to provide additional descriptive information to aid the designer in identifying a file.

The following properties are available in a MicroStation Design File: Title, Subject, Client, Keywords, and Comments.

For ODOT projects, the following properties shall be used for design files submitted to or exchanged with the Department:

**Title**

The Title property can be used to specify the file type description. If used, the description shall correspond to the file descriptions for each file type shown in **Figure 304-1 - File Name Type Codes**, prefixed with the Discipline name (see the examples on the following page).

**Comments**

The Comments property can be used to provide additional descriptive information to aid the designer in identifying a particular file. Comments are user definable with the following guidelines:

For Roadway design files the comment should start with the route name/number, where applicable, using the route name as follows:

|          |  |
|----------|--|
| IR###    | Interstate route with three-digit number, e.g. IR071 for Interstate route 71.  |
| US###    | United State route with three-digit number, e.g. US033 for US route 33.  |
| SR###    | State route with three-digit number, e.g. SR315 for State route 315.   |
| CR###    | County Road with three-digit number, e.g. CR056 for County road 56.  |
| RAMP###  | Ramp with up to three-character name/number, e.g. RAMP2S for ramp 2-S.   |
| ROADNAME | Road name, e.g. Paris for Paris road. Note, directions (N, S, E, W) can be used on projects where plans exist for two different directions of the same roadway, e.g. Paris N for Paris road north. |

Following the route name/number, the Comment property can contain additional information to help identify the specific sheet of the plan.

For Bridge design files, a brief description of the plan sheet contents should be included.

**Figure 304-1 File Name Type Codes**

| <b>Basemap Design Files</b> |    |
|-----------------------------|----|
| 3D Model                    | KB |
| 3D Modeling                 | KM |
| Aerial and Ground Combined  | BC |
| Aerial Mapping              | BA |
| Bridge                      | BS |
| Digital Terrain Model       | KD |
| Drainage                    | BD |
| Field Digital Terrain Model | FD |
| Geometry                    | BK |
| Geotechnical                | BI |
| Landscaping                 | BL |
| Lighting                    | BH |
| MOT                         | BM |
| Point Cloud                 | PC |
| Right-of-Way                | BR |
| Roadway                     | BP |
| Signals                     | BG |
| Superelevation              | KS |
| Survey Field Book           | FB |
| Traffic Control             | BT |
| Utilities                   | BU |
| Wall                        | BW |

| <b>Bridge Sheets</b>     |    |
|--------------------------|----|
| Bearing                  | SB |
| Deck Plan                | SD |
| Estimated Quantities     | SQ |
| Expansion Device Details | SX |
| Forward Abutment         | SF |
| Foundation Plan          | SO |
| General Notes            | SN |
| General Plan             | SG |
| Miscellaneous Details    | SM |
| Piers                    | SI |
| Railing                  | SA |
| Rear Abutment            | SR |
| Reinforcing Steel List   | SL |
| Removal                  | SV |
| Sheeting                 | SH |

|                             |    |
|-----------------------------|----|
| Site Plan                   | SP |
| Staged Construction Details | SC |
| Superstructure Details      | SS |
| Transverse Section          | ST |

| <b>Drainage Sheets</b>   |    |
|--------------------------|----|
| Channel Cross Sections   | XD |
| Culvert Details          | DC |
| Details                  | DD |
| Erosion Control          | DE |
| Miscellaneous Details    | DM |
| Notes                    | DN |
| Plan and Profile or Plan | DP |
| Profile                  | DF |
| Quantity Table           | DQ |
| Schematic Plan           | DB |
| Sub-Summary              | DS |

| <b>Geotechnical Sheets</b>                        |    |
|---|----|
| Geohazard Boring Logs                             | YL |
| Geohazard Cover                                   | YC |
| Geohazard Cross Sections                          | YX |
| Geohazard Lab Data                                | YD |
| Geohazard Plan and Profile                        | YP |
| Geohazard Profile                                 | YF |
| Soil Profile Cover                                | IC |
| Soil Profile Cross Sections                       | IX |
| Soil Profile Lab Data                             | ID |
| Soil Profile, Plan and Profile or Plan            | IP |
| Soil Profile, Profile Only                        | IF |
| Structure Foundation Exploration Boring Logs      | ZL |
| Structure Foundation Exploration Cover            | ZC |
| Structure Foundation Exploration Lab Data         | ZD |
| Structure Foundation Exploration Plan and Profile | ZP |
| Structure Foundation Exploration Profile          | ZF |

| <b>Landscaping Sheets</b> |    |
|---------------------------|----|
| Details                   | PD |
| Miscellaneous Details     | PM |
| Notes                     | PN |
| Plan                      | PP |
| Schematic Plan            | PB |
| Sub-Summary               | PS |

| <b>Lighting Sheets</b> |    |
|------------------------|----|
| Circuit Diagrams       | LC |
| Details                | LD |
| Elevation Views        | LE |

|                 |    |
|-----------------|----|
| General Summary | LG |
| Miscellaneous   | LM |
| Notes           | LN |
| Plan            | LP |
| Quantity Table  | LQ |
| Schematic Plan  | LB |
| Sub-Summary     | LS |

| <b>Maintenance of Traffic Sheets</b> |    |
|--------------------------------------|----|
| Cross Sections                       | XM |
| Detour Plan                          | MD |
| Miscellaneous                        | MM |
| Notes                                | MN |
| Phase Plan and Profile or Plan       | MP |
| Phase Details                        | MH |
| Profile                              | MF |
| Quantity Table                       | MQ |
| Schematic Plan                       | MB |
| Sub-Summary                          | MS |
| Typical Sections                     | MY |

| <b>Right-of-Way Sheets</b> |    |
|----------------------------|----|
| Centerline Plat            | RC |
| Legend                     | RL |
| Property Map               | RM |
| Railroad Plat              | RR |
| RW Boundary                | RB |
| RW Detail                  | RD |
| RW Topo                    | RT |
| Summary of Additional RW   | RS |

| <b>Roadway Sheets</b>            |    |
|----------------------------------|----|
| Calculations/Computations        | GC |
| Cross Sections                   | XS |
| Drive Details                    | GD |
| Fencing Plan                     | GX |
| General Notes                    | GN |
| General Summary                  | GG |
| Grading Plan                     | XG |
| Guardrail/Barrier Details        | GR |
| Intersection/Interchange Details | GI |
| Maintenance Data                 | GJ |
| Miscellaneous                    | GM |
| Pavement Details                 | GA |
| Plan and Profile or Plan         | GP |
| Profile                          | GF |
| Quantity Table                   | GQ |
| Schematic Plan                   | GB |

|                      |    |
|----------------------|----|
| Sub-Summary          | GS |
| Superelevation Table | GE |
| Title Sheet          | GT |
| Typical Sections     | GY |

| <b>Signal Sheets</b> |    |
|----------------------|----|
| Details              | CD |
| General Summary      | CG |
| Miscellaneous        | CM |
| Notes                | CN |
| Plan                 | CP |
| Quantity Table       | CQ |
| Sub-Summary          | CS |

| <b>Traffic Control Sheets</b> |    |
|-------------------------------|----|
| Calculations/Computations     | TC |
| Details                       | TD |
| Elevation Views               | TE |
| General Notes                 | TN |
| General Summary               | TG |
| Miscellaneous                 | TM |
| Plan                          | TP |
| Quantity Table                | TQ |
| Schematic Plan                | TB |
| Sub-Summary                   | TS |

| <b>Utility Sheets</b>     |    |
|---------------------------|----|
| Calculations/Computations | UC |
| Details                   | UD |
| Elevation Views           | UE |
| General Summary           | UG |
| Miscellaneous             | UM |
| Notes                     | UN |
| Plan and Profile or Plan  | UP |
| Profile                   | UF |
| Quantity Table            | UQ |
| Schematic Plan            | UB |
| Sub-Summary               | US |

| <b>Wall Sheets</b>        |    |
|---------------------------|----|
| Calculations/Computations | WC |
| Cross Sections            | WX |
| Details                   | WD |
| Elevation                 | WE |
| Estimated Quantities      | WQ |
| Foundation                | WT |
| Miscellaneous             | WM |
| Notes                     | WN |

|                          |    |
|--------------------------|----|
| Plan and Profile or Plan | WP |
| Profile                  | WF |
| Schematic Plan           | WB |
| Sheeting                 | WH |
| Steel List               | WL |
| Sub-Summary              | WS |
| Typical Section          | WY |

For additional information see [Appendix – File Naming Format](#).

## **305 Geographic Coordinate Systems**

### **305.1 General**

A Geographic Coordinate System (GCS) is used to specify the position of the design contents on the earth's surface. A library of standard GCSs is provided with MicroStation CE and ORD. Additionally, a custom system can be defined for ODOT projects mapped to ground coordinates.

The GCS shall be appropriately defined for all design files exchanged with the department.

See ODOT's training material for OpenRoads Survey for information about assigning the GCS to the Seed files for a project.

See the **ODOT Survey and Mapping Specifications Manual, Section 300** for information on positioning and control specifications.

## **306 OpenRoads Designer**

### **306.1 Federated Files**

OpenRoads data is stored in multiple discipline specific basemap design files as summarized below.

#### **306.1.1 Alignment Design Files**

For projects with more than one alignment a federated file approach will be used, where each alignment and corridor are stored in its own design file, the BK Geometry Basemap. Each file is numbered consecutively using a three-digit number as detailed in section 304 of this manual. The BK000 file shall be used as a collector file with each subsequently numbered BK file attached as a reference.

#### **306.1.2 Corridor Modeling Design Files**

Each OpenRoads corridor shall be stored in its own design file, the KM Corridor Modeling file. Each file is numbered consecutively using a three-digit number as detailed in section 304 of this manual. The KM000 file shall be used as a collector file with each subsequently numbered BK file attached as a reference.

#### **306.1.3 Survey Design Files**

OpenRoads Survey information is processed in its own design file. (i.e. the FB basemap file)

### 306.1.4 OpenRoads Subsurface Utilities Files

The OpenRoads Subsurface Utility commands require that a utility database is created in the design file. For this reason, subsurface utility information should be placed in its own design file. (i.e. the BD basemap file)

### 306.2 Alignment Names for OpenRoads Designer

To facilitate the efficient sharing and transfer of Alignment information between consultants, ODOT, and contractors, the OpenRoads Designer Element Names detailed below have been established.

The following element names for horizontal and vertical alignments have been established for OpenRoads Civil Geometry elements.

| <b>Horizontal Alignments</b>                   |              |
|--|--------------|
| Alternates Existing                            | AX#_rddd%%   |
| Alternates Proposed                            | AP#_rddd%%   |
| Baseline Existing                              | BLX_rddd%%   |
| Baseline Proposed                              | BLP_rddd%%   |
| Centerline Existing                            | CLX_rddd     |
| Centerline Proposed                            | CLP_rddd     |
| Centerline MOT Existing                        | CLX_MOT_rddd |
| Centerline MOT Proposed                        | CLP_MOT_rddd |
| Centerline Right of Way Existing               | CLX_RW_rddd  |
| Centerline Right of Way Proposed               | CLP_RW_rddd  |
| Centerline of Survey                           | CLX_SV_rddd  |
| Where:   |              |
| r = Route Type                                 |              |
| C = County Road                                |              |
| I = Interstate Route                           |              |
| R = Ramp                                       |              |
| S = State Route                                |              |
| T = Township Road                              |              |
| U = U.S. Route                                 |              |
| ddd = 3 digit route number 020, 270, 142, etc. |              |
| %% = 1-2 digit ramp number A, 2S, 3A, etc.     |              |
| # = 1 digit number 1, 2, ...                   |              |

Note: If the route type is unknown or the road is a local street, the “rddd” code should be replaced with the street name ensuring that the resulting horizontal alignment name is no longer than 12 characters.

For projects where multiple alternates are considered, once the alignment and profile have been selected, they should be renamed and given the name of the proposed elements. This will ensure that the proposed alignments are named uniquely rather than just being one of the many alternatives.



| <b>Vertical Alignments</b>  |   |
|-----------------------------|---|
| Existing Profile            | XGL_name  |
| Proposed Profile            | PGL_name  |
| Proposed Profile Alternates | A#_name   |
| Where:                      |   |
| name                        | = The name of the horizontal alignment the profile is associated with |
| #                           | = 1-digit number 1, 2, 3, etc.  |

The following element names have been established for OpenRoads Geometry elements used to define right-of-way.

| <b>Right of Way Parcels</b>   |   |
|---|---|
| Parent Tract  | ##  |
| Types of Title  | ##-ppppnz   |
| where:  |   |
| ##  | = 2 or more-digit number 01, 02, 03, . . .                    |
| Note: The number for the Types of Title shall match the number of the Parent Tract. |   |
| pppp  | = 1 to 4-character parcel identification code as shown below. |
| <b>Fee Simple Title</b>   |   |
| Acquired Fee Simple Excess Land   | EL  |
| Excess Land Sold or Swapped   | ES  |
| Fee Simple Excess Land  | E   |
| Fee Simple Uneconomic Remnant   | ER  |
| Property Right Fee Simple   | PRW   |
| Limitation of Access  | WL  |
| Reservation of Access   | WD  |
| <b>Easements</b>  |   |
| Aerial  | A   |
| Channel   | CH  |
| Flowage   | FL  |
| Limited Access  | LA  |
| Property Right  | PRE   |
| Railroad or Public Utility  | U   |
| Scenic Easement   | SC  |
| Standard Highway  | SH  |
| Sewer   | S   |
| Slope   | SL  |
| Temporary Easement  | T   |
| <b>Agreements</b>   |   |
| Work  | WA  |
| <b>Others</b>   |   |
| Present Road Occupied (PRO)   | PRO   |
| PRO Inside  | PROI  |

|  |      |
|--|------|
| PRO Total  | PROT |
| <p>n = When the parent tract has multiple types of title of the same type, a 1-digit number is used to identify each Type of Title.</p>  |      |
| <p>z = Additional Modifiers:</p>   |      |
| In the name of another State agency, LPA, etc.   | V    |
| Special Reservation  | R    |
| <p>Examples:</p> <p>03 (parent tract)</p> <p>03-LA (easement for parent tract 03)</p> <p>03-WD1 (taking for parent tract 03)</p> <p>03-PRO (occupied area for parent tract 03)</p> |      |

### 306.3 Survey Point Names

The following point name prefixes have been established for OpenRoads survey points.

| Point Name Prefix | Usage   |
|-------------------|---|
| AT                | Aerial Mapping Control (including targets and picture points) |
| BM                | Benchmarks (Permanent Benchmarks Only)                        |
| CP                | Control Points (this includes Geodetic and Primary Control)   |
| MV                | Monument Points (Centerline, RW, Property Pins...)            |
| SV                | Survey Points (All mapping/topo)                              |

## 400 PLOTTING

---

### 401 General

#### 401.1 General

ODOT requires multi-page PDF files for plan submissions. PDF printing is facilitated using the MicroStation Print Organizer.

**Print Organizer** is a MicroStation utility for printing and reprinting a set of design files, models, or Project Explorer links. The files that are to be printed are saved as a print set, (PSET), file.

ODOT includes a template PSET file, OHDOT\_seed.pset, prepopulated with folders to organize the design files that will make up the print. The PSET folder structure mimics the plan set structure from **Section 1300** of the **Location and Design Manual, Volume 3**. Additional directories can be added if needed. When the PDF is generated, the empty directories will not be included. The PSET folder names become the multi-page PDF bookmarks.

In the OHDOT\_Styles\_Printing.dgnlib, Print Styles are defined that control the output from Print Organizer. Print Styles include ODOT standard Plot Configuration Files and Pen Tables and enable generation of PDF files as well as printed output. The OHDOT\_Styles\_Printing.dgnlib also defines a named expression, ODOT\_SheetName, which can be applied to the plot set. This reads the model description from the model property and applies it to the name of the page in the PSET. The template PSET file uses this named expression as the default. If the Sheet Name in Model Properties is blank, then the Model Name from the Model Properties dialog is used as the default page name.

ODOT uses pen tables that are applied to the graphical elements when the design file is plotted. The pen tables translate various elements in the design file to the final output version.

Elements should be plotted in color. The major grid level is set to a lower priority, so it will plot under most plan sheet details. Cross section and profile grids should be plotted as shown in the **Location and Design Manual, Volume 3, Figure 1202-1**.

Standard MicroStation plotting files are included in ODOT's CADD Standards download, available on the **Office of CADD and Mapping Services, CADD Services** web page. The files available for download include user documentation. Also, see **PDF Printing with Print Organizer** in the **Project Management with the OHDOT Standards** Training Guide for additional details.

#### 401.2 Plotting

MicroStation pen tables and Printer Driver Configuration files for use with MicroStation Connect and OpenRoads Designer are located in the following directory for ODOT users:

```
..\OHDOT_CONNECT\WorkSpaces\OHDOT\Standards\Pltcfg\
```

Plotting documentation is located here:

```
..\OHDOT_CONNECT\WorkSpaces\OHDOT\Standards\OHDOTUtilities\Documentation\Plotting\
```

The plotting documentation has detailed settings and usage information. The following briefly describes the Printer Configuration Files.

| Printer Driver Files    | Description                                   | Default Page Size |
|-------------------------|---|-------------------|
| OHDOT.pltcfg            | Used for printing to windows print queue      | 17" x 11"         |
| OHDOT_PDF.pltcfg        | Used for printing in black to PDF file format | 34" x 22"         |
| OHDOT_PDF_Color.pltcfg  | Used for printing in color to PDF file format | 34" x 22"         |
| OHDOT_PDF_Levels.pltcfg | Used for printing levels to PDF file format   | 34" x 22"         |

| Pen Table Files | Description            |
|-----------------|------------------------|
| OHDOT_Pen.tbl   | Used to print in black |
| OHDOT_PenC.tbl  | Used to print in color |

Note: Elements not handled by the Shading or Masking sections of the OHDOT\_Pen.tbl are plotted in black. Elements not handled by the Shading or Masking sections of the OHDOT\_PenC.tbl are plotted in color.

#### 401.2.1 Line Weights

The Printer Driver Files specify the MicroStation element weight to output line thickness. Line weights in the configuration files are defined as below for 22"x34" Prints. The configuration files set the Weight Scale to 0.5 for 11"x17" and 8 ½"x11" prints, so the thickness is one-half the values shown in the table. The Style Scale is also set to 0.5 for 11"x17" and 8 ½"x11" prints, reducing the dash and gap lengths of standard MicroStation line styles by one half. Though line thicknesses are defined to weight 10, only weights 0-5 are used in ODOT's level standards:

| Element Weight | Thickness (approximate inches) |
|----------------|--------------------------------|
| WT = 0         | 0.006"                         |
| WT = 1         | 0.014"                         |
| WT = 2         | 0.026"                         |
| WT = 3         | 0.036"                         |
| WT = 4         | 0.046"                         |
| WT = 5         | 0.056"                         |
| WT = 6         | 0.066"                         |
| WT = 7         | 0.076"                         |
| WT = 8         | 0.086"                         |
| WT = 9         | 0.096"                         |
| WT = 10        | 0.106"                         |

Due to the variation in plotting accuracy of various printers, the thicknesses shown in the table above can be modified as deemed necessary to achieve the desired results.

#### 401.2.2 Priority and Transparency

Plotting priorities are determined by the MicroStation level and the assigned element Priority values in the **ODOT\_Feature\_Definitions.dgnlib**. Priority and Transparency are not handled in the ODOT standard pen tables.

### 401.2.3 Shading

The following functionality to shade various plan sheet elements is included in the OHDOT\_Pen.tbl and OHDOT\_PenC.tbl:

#### Cross Section Grid

The pen tables shade the Major Cross Section grid using the following settings:

Major Grid – uses Color = 42 (RGB Value = 176, 176, 176)

#### Shading Filled Shapes

Shading levels were created to fill shapes with varying shades of Gray. The pen table fills shapes based on the following shading levels:

SC\_Shading1 – uses Color = 41 (RGB Value = 160, 160, 160)

SC\_Shading2 – uses Color = 43 (RGB Value = 192, 192, 192)

SC\_Shading3 – uses Color = 45 (RGB Value = 224, 224, 224)

#### Shading Reference(s)

To gray shade a reference, the Logical Name must begin with gray, for example gray1, gray2, etc. Color 41 (RGB Value = 160, 160, 160) is used to gray shade references. When plotting a reference using a logical name beginning with gray, the pen table will gray shade the entire reference.

#### Title Sheet Shading

Corporation boundaries and route shields fill on the Title Sheet Area Map are handled in the pen table.

### 401.2.4 Masking

Masking is an option to hide specific areas on a plan sheet. No elements will show underneath.

The Masking level plots all elements, or filled shapes, as White to mask any elements underneath. The pen table processes elements on the following masking level:

SH\_Masking – uses Color = 255 (Background Color)

### 401.2.5 Text Substitution

The pen tables handle text replacement on sheet borders to insert information such as file name, model name, date, time, etc. The text replacement string is located on a sheet border on the left side. See the table below for the text replacement settings.

| Text String | Default Settings                             |
|-------------|--|
| *****       | File Name, Model Name, Date, Time, Username  |
| *****       | Model Name, Paper Size, Date, Time, Username |
| *****       | File Name                                    |

#### 401.2.6 Color Plotting

The **OHDOT\_PenC.tbl** is used for producing color output of an ODOT plan sheet. This pen table does the Major Cross Section shading and Reference shading the same as above. Some text on the SH\_Data level is changed from White to Black by the pen table, so that it will display. Text substitution is handled as above. All other elements are plotted in their display colors.